

CatGenie™ SideWalls Assembly



1. Align the fronts of the two SideWalls vertically.



2. Gently push the right side up and the left side down until they are locked together.



3. Put the SideWalls onto the top of the CatGenie Brim. Then gently press the SideWalls down onto the Brim, pressing all around the top of the SideWalls until they are securely in place.



GenieDome™Tops
are also available.

www.catGenie.co.uk

